



HYDROTAP G5 BCHA20 4-IN-1 CLASSIC PLUS TAP WITH ARC MIXER BRUSHED NICKEL



BOILING



CHILLED



HOT & AMBIENT

FILTERED

UNFILTERED

Order Code H55821Z11AU

Zip HydroTap Classic Plus 4 in 1 Boiling, Chilled, Filtered water plus Hot and Cold washing up water from two separate taps. The system features a single under bench command centre including full colour interactive touch screen display with pin code protection and customisable settings including 2 boiling water safety modes, 3 energy saving modes including ON/OFF timers and sensor activated 'sleep when it's dark', 'Quiet' mode with automated intelligent fan speed adjustment, SteriTouch® antimicrobial protection impregnated into key water paths for enhanced hygiene, 100% water efficient air cooled technology, and 0.2 micron water filtration.



Manufacturing Code H55821Z11AU

Capacity Commercial

Boiling Cups per hour 100

Chilled Cups per hour 75

Tap Zip HydroTap CLASSIC PLUS Tap (Brushed Nickel)

Water Pressure Min 300kPa - Max 700kPa

Water Connection 1/2" BSP (G1/2)

Water Supply Requirements Cold

Water Valves Integrated 500kPa Pressure limiting valve and Dual Check Valve

Power Rating 1.9kW 220-240V 50Hz

Power Supply	1 x 10 Amp socket outlet
Dimensions	W280mm x D455mm x H333mm
Product Approvals	WaterMark, RCM, ARC
Wels Rating	5 Star, 5.5 litres
Warranty	5 years (appliance warranty 36 months plus additional 24 months tank warranty)

Installation Requirements

'1. Installation and connection of your Zip HydroTap must be carried out by a qualified person, observing national and local regulations. 2. You will require suitable mains electrical and drinking water connections, plus waste water drainage all within 1.5 metres of the product. 3. HydroTap is air-cooled so discrete cabinetry cut-outs are required for ventilation. 4. Installation on most bench tops is straightforward however some stone bench tops may require a specialised cutting service. 5. If you live in a hard water area, we recommend installation of a Zip scale filtration kit. 6. Installation by Zip Professional Service can be arranged with a phone call or through www.zipwater.com'

Installation Detail

BKL2 HydroTap G5 v1.01 03.21 BC BC20

Ventilation requirements Contact your local service provider if ventilation is not suitable

Clearance envelope
Position the Tap and the Command Centre as close together as possible.

200
333
50
Command Centre width 50

HydroTap Tap options

Classic Plus: 116, 216, 128, 128, 116, 128, 116, 128, 112, 134, 116, 128, 116, 128, 112, 134, 116, 128, 116, 128, 112, 134

Touch-Free Wave: 116, 214, 128, 100, 100mm clearance envelope required. For Sink installations, install on the left-hand side of the Sink for ease of access to Boiling water function.

Mixer Tap options

Arc Mixer Tap: 281, 256, 220, 206, 146, 434, 45, 86, 206, 146, 86, 73, 362, 45, 86, 73, 362

Cube Mixer Tap: 281, 256, 218, 206, 146, 86, 73, 362, 45, 86, 73, 362

Classic Mixer Tap: 198, 224, 233, 270, 198, 224, 233, 270

Accessible Mixer Tap: 165, 250, 198, 233, 270, 165, 250, 198, 233, 270

Tap Positioning
Position the Tap to dispense into the sink, allowing clearance for a cup or teapot. Alternatively, mount the HydroTap Tap on a Font (available as an accessory).

35mm hole for HydroTap Tap 35mm hole for Mixer Tap

Air outlet louvre (if required)
Cut-out in door/wall, towards the top of the cabinet

285 60

Air inlet cut-out (required)
Cut-out in cabinet floor

max. 43 326

Vented Arc Mixer Tap (optional)

4mm buffer pad air space

Classic Plus Tap

Clearance Envelope
IEC Flex & Plug 230-240V, 50Hz power outlet
Air inlet grille

Vented mixer tap installation
Only cold water supply required

35mm hole in sink/benchtop for mixer tap
RED marked braided hose to HydroTap Command Centre MIXER OUT
BLUE marked braided hose to HydroTap Command Centre MIXER IN
WHITE marked braided hose
Braided hose to HydroTap Command Centre MAINS inlet
Mains water isolation valve (not supplied)

HydroTap G5 BC20 H
shown with "Classic Plus" Tap and Arc Mixer Tap (V)

SCALE 1:5
ALL DIMENSIONS IN MM UNLESS OTHERWISE SPECIFIED. INSTALLATION DIAGRAMS ARE FOR ILLUSTRATIVE PURPOSES ONLY. HOSES ARE NOT SHOWN TO SCALE AND CANNOT BE LENGTHENED.

